



Pcounter for HP

Compatibility List

Pcounter Embedded for HP
2019.08.06

A.N.D. Technologies
4104 24th Street #627
San Francisco, CA 94114
USA

E-Mail: support@pcounter.com

Web: <http://www.pcounter.com>

Phone: (415) 701-9222

Fax: (415) 651-9000

Copyright © 2019

0.0.0 Introduction

Pcounter for HP is server software that is intended to reside on a Window server.

Pcounter for HP is used to control walkup user access (**authentication**) to HP MFPs as well as capture walkup usage (**accounting**) for copy, scan, and fax.

A quick technical note; MFP = Multifunction Printer, and in this instance the MFP is the HP printer being configured.

0.0.1 Trial Period Information

Without a valid registration number, the Pcounter for HP software runs will run with full functionality for 90 days in trial mode. During this time there are no restrictions to the software's functionality and it can be used for testing all features. At the end of the trial period a valid registration number must be inserted, or the software will no longer function until a valid registration number is entered.

1.0.0 Goal

The goal of this document is to provide a list of supported MFP models for Pcounter Embedded for HP.

1.1.0 What is Pcounter for HP

Pcounter for HP is Windows server software that interfaces directly with the embedded operating system inside the MFP. Pcounter for HP works in combination with Pcounter for Windows. Pcounter for HP provides a point of access control (Authentication), the ability to log job based data for copy, scan, and fax (Logging), and the ability to assign page quotas or currency balances to users, debiting them for individual jobs (Accounting).

Pcounter for HP combines all MFP print, copy, and scan data into a single log file managed by the Pcounter for Windows Data Server. Reporting can then be done quickly and easily for all job types using Pcounter Administrator and Pcounter Web Report.

1.2.0 Requirements

Please see our Pcounter System Requirements document at:

http://apps.pcounter.com/docs/pcounter_system_requirements.pdf

The Pcounter for HP server software can be installed on Windows 2008R2 Server or any later Windows "business" operating system. Windows "Home" products that lack domain support are not recommended.

The Pcounter for Windows software (version 2.90a or later) must be previously installed, configured, and in use on the Windows print server before installing and configuring the Pcounter for HP embedded management software on the server.

For more detailed information about Pcounter installation and administration please refer to the Pcounter Setup Guide and the Pcounter Documentation PDFs on the Pcounter Wiki at:

<https://pcounter.wixanswers.com>

Pcounter for Windows can be downloaded from <http://www.pcounter.com>

To download Pcounter for HP please contact Pcounter support at support@pcounter.com

1.0.0 Unsupported Models

The following models do not support Pcounter for HP Embedded. There may be more models that are not supported.

- LaserJet Pro 400 M451nw
- LaserJet Pro 400 M452nw
- LaserJet Pro MFP M521dn
- Color LaserJet Pro 400 MFP M475dw
- Color LaserJet Pro 400 MFP M476dn
- Color LaserJet Pro 400 MFP M425dn
- Officejet Pro x551dw
- Page Wide Pro 552 / P55250
- Page Wide Pro M477 / 577 / 577dw / P57750
- P4015x
- P77440dn
- P77940
- P77950
- P77960

2.0.0 Supported Models

The following models support Pcounter for HP Embedded though some may not support all features.

2.1.0 LaserJet

- LaserJet 4345 MFP
- LaserJet 9000 MFP
- LaserJet 9040 MFP
- LaserJet 9050 MFP
- LaserJet 9500 MFP
- LaserJet M3035 MFP
- LaserJet M4345 MFP
- LaserJet M4349 MFP
- LaserJet M5035 MFP
- LaserJet M5039 MFP
- LaserJet M9040 MFP
- LaserJet M9050 MFP
- LaserJet M9059 MFP
- LaserJet MFP CM4540
- LaserJet MFP M525 / Flow M525)
- LaserJet MFP M527
- LaserJet MFP M725
- LaserJet MFP M775
- LaserJet M4555 MFP
- LaserJet MFP M830
- LaserJet MFP M880z
- LaserJet E52545 MFP / LaserJet Flow E52545 MFP

- LaserJet E50045
- LaserJet M5035 MFP / LaserJet M5039 MFP
- LaserJet M525 MFP / LaserJet Flow M525 MFP
- LaserJet M4555 MFP
- LaserJet Enterprise M830 MFP
- LaserJet M725 MFP
- LaserJet M630 MFP / LaserJet Flow M630 MFP
- LaserJet M712
- LaserJet M806
- LaserJet M601/M602/M603
- LaserJet M604 / M605 / M606
- LaserJet M506
- LaserJet M527 MFP
- LaserJet Managed (Flow) MFP E72525/E72530/E72535
- LaserJet Managed (Flow) MFP E82540/E82550/E82560
- LaserJet Enterprise M631 (Flow)/M632 (Flow) / M633 (Flow) MFP
- LaserJet Managed E62555/E62565 (Flow)/E62575 Flow MFP
- LaserJet Enterprise M607/M608/M609
- LaserJet Managed E60055/E60065/E60075
- LaserJet MFP M630
- LaserJet MFP Flow M630
- LaserJet 600 M601/602/603/604/605/606
- LaserJet 700 M712
- LaserJet Color M750
- LaserJet M806
- LaserJet M855

2.2.0 Color LaserJet

- Color LaserJet MFP M575 / Flow M575
- Color LaserJet MFP M577 / M577dn
- Color LaserJet MFP E77820 / E77822 / E77825 / E77830
- Color LaserJet CM6030 MFP
- Color LaserJet CM6040 MFP
- Color LaserJet CM6049 MFP
- Color LaserJet CM3530 MFP
- Color LaserJet CM4730 MFP
- Color LaserJet 4730 MFP
- Color LaserJet E57540 MFP / Color LaserJet Flow E57540 MFP
- Color LaserJet E55040
- Color LaserJet M575 MFP / Color LaserJet Flow M575
- Color LaserJet CM4540 MFP
- Color LaserJet M775 MFP
- Color LaserJet Enterprise Flow M880 MFP
- Color LaserJet Enterprise M680 Flow / Non-Flow MFP
- Color LaserJet M855
- Color LaserJet M551
- Color LaserJet CP 5525
- Color LaserJet M651
- Color LaserJet M750
- Color LaserJet M552 / M553
- Color LaserJet M577 MFP
- Color LaserJet Enterprise Flow M680 MFP
- Color LaserJet Enterprise Flow M682(z) MFP
- Color LaserJet Managed (Flow) MFP E77822/E77825/E77830
- Color LaserJet Managed (Flow) E87640/E87650/E87660
- Color LaserJet Enterprise M681 (Flow) MFP
- Color LaserJet Managed E67550 MFP
- Color LaserJet Enterprise M652/M653
- Color LaserJet Managed E65050/E65060
- Color LaserJet Enterprise Flow M680 MFP
- Color LaserJet Enterprise Flow M682(z) MFP
- Color LaserJet CP5520 Series
- Color LaserJet 500 M551
- Color LaserJet CP5525
- Color LaserJet Enterprise M651
- Color LaserJet M552/M553

2.3.0 OfficeJet / Color OfficeJet

- Color Officejet X555 MFP
- Color Officejet Enterprise X585 MFP
- Color Officejet Enterprise X555
- Color OfficeJet Enterprise X585 Flow / Non-Flow MFP

2.4.0 PageWide

- PageWide Enterprise Color 586 / E58653
- PageWide Managed Color MFP E77650 / E77660
- PageWide Managed Color E55653
- PageWide Managed Color / Color Flow MFP E58650
- PageWide Enterprise Color / Color Flow MFP 556 / 586
- PageWide Enterprise Color 765
- PageWide Enterprise Color MFP 780
- PageWide Enterprise Color Flow MFP 785
- PageWide E77650 / E77660
- PageWide Pro M477 MFP
- PageWide Pro 577 MFP
- PageWide MFP P57750 (Managed)
- PageWide Pro 552 Printer
- PageWide P55250 (Managed)
- PageWide Pro 750
- PageWide Managed P75050
- PageWide Pro 772/777 MFP
- PageWide Managed P77740/P77750/P77760 MFP

2.5.0 Scanjet

- ScanJet Enterprise Flow N9120 fn2
- Scanjet Enterprise 8500

2.6.0 Digital Sender

- Digital Sender MFP 9250C
- Digital Sender Flow 8500 fn2

2.7.0 Digital Sender

- Deskjet 880c

3.0.0 Documentation and Video Links

Download or view this guide online at:

http://apps.pcounter.com/docs/HP_Chart.pdf

Please view all Pcounter Videos online at: <https://www.youtube.com/andtechsf/>

Please also visit our Pcounter Support website at: <https://pcounter.wixanswers.com/en/>

This concludes the guide. If there are any questions, please email support@pcounter.com